


# WHITE



## OUTDOOR POWER

**SNOW BOSS 500  
SNOW BOSS 850  
SNOW BOSS 1050**






(Model 646F Shown)

**Model Nos.  
315-616E190  
315E646F190  
315E666H190**

**Thank you for purchasing  
an American-built product.**

# IMPORTANT

## SAFE OPERATION PRACTICES

 THIS SYMBOL POINTS OUT IMPORTANT SAFETY INSTRUCTIONS WHICH, IF NOT FOLLOWED, COULD ENDANGER THE PERSONAL SAFETY AND/OR PROPERTY OF YOURSELF AND OTHERS. READ AND FOLLOW ALL INSTRUCTIONS IN THIS MANUAL BEFORE ATTEMPTING TO OPERATE YOUR SNOW THROWER. FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY. WHEN YOU SEE THIS SYMBOL—  **HEED ITS WARNING.** 



### DANGER:

Your snow thrower was built to be operated according to the rules for safe operation in this manual. As with any type of power equipment, carelessness or error on the part of the operator can result in serious injury. If you violate any of these rules, you may cause serious injury to yourself or others.



### TRAINING

1. Read this owner's guide carefully in its entirety before attempting to assemble or operate this machine. Be completely familiar with the controls and the proper use of this machine before operating it. Keep this manual in a safe place for future and regular reference and for ordering replacement parts.
2. Never allow children under 14 years old to operate a snow thrower. Children 14 years old and over should only operate snow thrower under close parental supervision. Only persons well acquainted with these rules of safe operation should be allowed to use your snow thrower.
3. No one should operate this unit while intoxicated or while taking medication that impairs the senses or reactions.
4. Keep the area of operation clear of all persons, especially small children and pets.
5. Exercise caution to avoid slipping or falling, especially when operating in reverse.



### PREPARATION

1. Thoroughly inspect the area where the equipment is to be used and remove all door mats, sleds, boards, wires and other foreign objects.
2. Disengage all clutches and shift into neutral before starting engine.
3. Do not operate equipment without wearing adequate winter outer garments. Do not wear jewelry, long scarfs or other loose clothing which could become entangled in moving parts. Wear footwear which will improve footing on slippery surfaces.
4. Before working with gasoline, extinguish all cigarettes and other sources of ignition. Check the fuel before starting the engine. Gasoline is an extremely flammable fuel. Do not fill the gasoline tank indoors, while the engine is running, or until engine has been allowed to cool at least two minutes. Replace gasoline cap securely and wipe off any spilled gasoline before starting the engine as it may cause a fire or explosion.
5. Use a grounded three wire plug-in for all units with electric drive motors or electric starting motors.
6. Adjust collector housing height to clear gravel or crushed rock surface.
7. Never attempt to make any adjustments while engine is running (except where specifically recommended by manufacturer).
8. Let engine and machine adjust to outdoor temperature before starting to clear snow.
9. Always wear safety glasses or eye shields during operation or while performing an adjustment or repair, to protect eyes from foreign objects that may be thrown from the machine in any direction.



### OPERATION

1. Do not put hands or feet near or under rotating parts. Keep clear of discharge opening and auger at all times.
2. Exercise extreme caution when operating on or crossing gravel drives, walks, or roads. Stay alert for hidden hazards or traffic. Do not carry passengers.
3. After striking a foreign object, stop the engine, remove wire from spark plug, and thoroughly inspect the snow thrower for any damage. Repair the damage before restarting and operating the snow thrower.
4. If the snow thrower should start to vibrate abnormally, stop the engine and check immediately for the cause. Vibration is generally a warning of trouble.

5. Stop engine whenever you leave the operating position, before unclogging the collector/impeller housing or discharge guide, and making any repairs, adjustments, or inspections. Never place your hand in the discharge or collector openings. Use a stick or wooden broom handle to unclog the discharge opening.
6. Take all possible precautions when leaving the unit unattended. Disengage the collector/impeller, shift into neutral, stop the engine, and remove the key.
7. When cleaning, repairing, or inspecting, make certain collector/impeller and all moving parts have stopped. Disconnect spark plug wire and keep away from plug to prevent accidental starting.
8. Do not run engine indoors, except when starting engine and transporting snow thrower in or out of building. Open doors. Exhaust fumes are dangerous.
9. Do not clear snow across the face of slopes. Exercise extreme caution when changing direction on slopes. Do not attempt to clear steep slopes.
10. Never operate snow thrower without guards, plates, or other safety protection devices in place.
11. Never operate snow thrower near glass enclosure, automobiles, window wells, drop off, etc., without proper adjustments of snow thrower discharge angle. Keep children and pets away.
12. Do not overload machine capacity by attempting to clear snow at too fast a rate.
13. Never operate the machine at high transport speeds on slippery surfaces. Look behind and use care when backing.
14. Never direct discharge at bystanders or allow anyone in front of unit.
15. Disengage power to collector/impeller when transporting or not in use.
16. Use only attachments and accessories approved by the manufacturer of snow thrower (such as wheel weights, counter weights, cabs, etc.).
17. Never operate the snow thrower without good visibility or light. Always be sure of your footing and keep a firm hold on the handles. Walk, never run.
18. Muffler and engine become hot and can cause a burn. Do not touch.



### MAINTENANCE AND STORAGE


1. Check shear bolts, engine mounting bolts, etc., at frequent intervals for proper tightness to be sure equipment is in safe working condition.
2. Never store the machine with fuel in the fuel tank inside a building where ignition sources are present, such as hot water and space heaters, clothes dryers, and the like. Allow engine to cool before storing in any enclosure.
3. Always refer to owner's guide instructions for important details if snow thrower is to be stored for an extended period.
4. Run machine a few minutes after throwing snow to prevent freeze up of collector/impeller.
5. Check clutch controls periodically to verify they engage and disengage properly and readjust if necessary. Refer to owner's guide for adjustment instructions.

# CONTENTS OF HARDWARE PACK

Lay out the hardware according to the illustration for identification purposes. Parts are illustrated approximately one-half size. Part numbers are shown in parentheses.


(Hardware pack may contain extra items which are not used on your unit.)

## A ATTACHING THE HANDLE ASSEMBLY




\*May be preassembled on your unit.


## B ATTACHING THE CHUTE ASSEMBLY



## C ATTACHING THE CHUTE CRANK




## D ATTACHING THE SHIFT ROD AND CLUTCH CABLES



## E AUGER SHEAR BOLTS

The augers are secured to the spiral shaft with two hex bolts and hex insert lock nuts. If you hit a foreign object or ice jam, the snow thrower is designed so that the hex bolts will shear. Two replacement hex bolts and nuts are provided for your convenience. Store in a safe place until needed.



# ASSEMBLY INSTRUCTIONS

**IMPORTANT:** This unit is shipped **WITHOUT GASOLINE or OIL**. After assembly, see separate engine manual for proper fuel and engine oil recommendations.

**NOTE:** Reference to right or left side of the snow thrower is from behind the unit in the operating position.

## Tools Required for Assembly:

- (2) 1/2" Wrenches\*
- (2) 7/16" Wrenches\*
- (1) Pair of Pliers
- \*or Adjustable Wrenches




FIGURE 1.




FIGURE 2.—Model 646F Shown

## UNPACKING

1. Remove staples or break glue on the top flaps of the carton. Remove any loose parts included with unit (i.e., owner's manual, etc.).
2. Cut along dotted lines and lay end of carton down flat. Remove packing material.
3. Roll unit out of carton. Check carton thoroughly for loose parts.

## Loose Parts in Carton:

- (1) Right Handle
- (1) Left Handle
- (1) Handle Panel Assembly and Chute Assembly (Attached by Cable)
- (1) Chute Crank Assembly
- (1) Shift Rod

## ATTACHING THE HANDLE ASSEMBLY (Hardware A)

1. Place right handle in position against the snow thrower so the flat side of the handle is against the snow thrower. Secure bottom hole in handle to snow thrower using hex bolt 5/8" long and lock washer. See figure 1. Do not tighten at this time.
2. Place handle tab over the upper hole in handle so the curve in the handle tab matches the curve in the handle. Secure to the snow thrower using hex bolt 1-3/4" long and lock washer. Do not tighten at this time.
3. Attach the left handle in the same manner. Do not tighten at this time.

**NOTE:** If the handle panel is already assembled to the handles, skip steps 4, 5 and 6. Go to step 7.

4. Place handle panel in position between the handles so the ends of the handle go through the slots in the handle panel. See figure 2.
5. Secure front of handle panel with four carriage bolts, cupped washers (cupped side against the handle panel) and hex nuts as shown in figure 2.
6. Secure rear of handle panel with two hex bolts, cupped washers (cupped side against the handle) and hex nuts.
7. Tighten the four hex bolts used to attach the bottom of the handles to the snow thrower frame.




FIGURE 3.

### ATTACHING THE CHUTE ASSEMBLY (Hardware B)

1. Grease the chute opening using a multi-purpose automotive grease or equivalent.
2. Place chute assembly over chute opening, with the opening in the chute assembly facing the front of the unit. Place chute flange keepers beneath lip of chute assembly. Insert hex bolt up through chute flange keeper and chute assembly as shown in figure 3. Secure with hex lock nut. After assembling all three chute flange keepers, tighten all nuts and bolts securely, then back off 1/4 turn to allow easier movement.




FIGURE 4.

### ATTACHING THE CHUTE CRANK (Hardware C)

1. Insert hex bolt through the upper chute crank bracket. See figure 4.
2. Place the hex bolt into the hole provided in the left handle. Secure with lock washer and hex nut. Do not tighten until after attaching the other end of the chute crank.




FIGURE 5.

3. Loosen the carriage bolts and hex lock nuts which secure the lower chute crank bracket to the extension on the left side of the chute assembly. See figure 5.




FIGURE 6.

4. Place one flat washer on the end of the chute crank, then insert the end of the crank into the hole in the plastic bushing in the chute crank bracket. See figure 6. Place the other flat washer on the end of the chute crank, and insert cotter pin into hole in the end of crank. Secure by bending the ends of cotter pin in opposite directions.



5. Adjust the chute bracket so that the spiral on the chute crank fully engages the teeth on the chute assembly. Tighten the nuts on the lower chute crank bracket securely. Tighten the hex bolt and nut on the upper chute crank bracket on the handle.




FIGURE 7.

6. **Models 646F and 666H only:** Slip the cables that run from the handle panel to the chute into the cable guide located on top of the engine. See figure 7.

**IMPORTANT:** Attach the shift rod and clutch cables as follows. **THEN CHECK THE ADJUSTMENTS AS INSTRUCTED, AND MAKE ANY FINAL ADJUSTMENTS NECESSARY BEFORE OPERATING YOUR SNOW THROWER.** Failure to follow the instructions may cause damage to the snow thrower.




FIGURE 8.

### ATTACHING THE SHIFT ROD (Hardware D)

1. Insert the ferrule through the **lower** hole in the shift lever (beneath the handle panel) from the left side. Secure with flat washer and hairpin clip. See figure 8.
2. Place the shift lever in the sixth (6) speed position (all the way forward).
3. Start threading the shift rod into the ferrule. Push down on the shift arm assembly as far as it will go. Thread shift rod into the ferrule until the end of the shift rod lines up with the hole in the shift arm assembly. Secure with spring washer, flat washer and hairpin clip.

Make certain to check for correct adjustment of the shift rod as instructed in the Final Adjustment section before operating the snow thrower.

### ATTACHING THE CLUTCH CABLES

The "Z" end of the clutch cables are hooked into the clutch grips on each handle. Attach cables as follows.

1. Thread the hex lock nuts (in hardware pack) **all the way up** the threaded portion of the "Z" ends of the clutch cables.
2. Make certain each cable is in groove of cable roller guides. Place the clutch grip in the raised (up) position.
3. Thread the cable onto the threaded portion of the "Z" end until there is no slack in the cable, but the **cable is NOT tight. Do not overtighten cable.** See figure 9.



**WARNING:** If cable is tightened so there is tension on the cable with the clutch grip released, the safety features of the snow thrower may be overridden.

4. When correct adjustment is reached, tighten the hex nut against the bottom portion of the cable to lock it in position.




FIGURE 9.

## FINAL ADJUSTMENTS

### Auger Drive Clutch

To check the adjustment of the auger drive clutch, push forward on the left hand clutch grip (depress the rubber bumper). There should be slack in the cable. Release the clutch grip. The cable should be straight. Make certain you can depress the auger drive clutch grip against the left handle completely.

If necessary, loosen the hex lock nut and thread the cable in (for less slack) or out (for more slack) as necessary. Refer to figure 9. Recheck the adjustment. Tighten the lock nut against the cable when correct adjustment is reached.

### Traction Drive Clutch and Shift Lever Adjustment

To check the adjustment of the traction drive clutch and shift lever, tip the snow thrower forward so that it rests on the auger housing. First move the shift lever all the way forward to sixth (6) position. With the traction drive lever released, spin the snow thrower wheels by hand. They should turn freely. Then engage the traction drive clutch grip. The wheels should stop turning.

Now release the traction drive clutch grip, and spin the wheels again. Move the shift lever back to the fast reverse position, then all the way forward again. There should be no resistance in the shift lever, and the wheels should keep turning.

If you have resistance when moving the shift lever or the wheels stop when they should not, loosen the lock nut on the traction drive cable and unthread the cable one turn. If the wheels do not stop when you engage the traction drive clutch grip, loosen the lock nut on the traction drive cable and thread the cable in one turn. Recheck the adjustment and repeat adjustment as necessary. Tighten the lock nut to secure the cable when correct adjustment is reached.

**NOTE:** If you are uncertain that you have reached the correct adjustment, refer to the Adjustment section on page 10.

## ADJUSTING THE SKID SHOES

The space between the shave plate and the ground can be adjusted. For close snow removal, place skid shoes in the low position. Use middle or high position when area to be cleared is uneven. See figure 10.

Adjust skid shoes by loosening the four hex nuts and carriage bolts and moving skid shoes to desired position. Make certain the entire bottom surface of skid shoe is against the ground to avoid uneven wear on the skid shoes. Retighten nuts and bolts securely.




FIGURE 10.

## OPTIONAL ELECTRIC STARTER

If your unit is equipped with an optional electric starter which has not been installed at the factory, install at this time. Follow the instructions packed with the electric starter for installation.

## TIRE PRESSURE (Pneumatic Tires)

The tires are over-inflated for shipping purposes. Check tire pressure and reduce to 15 to 20 psi.

**NOTE:** If the tire pressure is not equal in both tires, the unit may pull to one side or the other.

# CONTROLS




FIGURE 11.—Model 646F Shown

## SHIFT LEVER

(See figures 11 and 12)

The shift lever is located in the center of the handle panel. The shift lever may be moved into one of eight positions. Run engine with throttle in the fast position. Use the shift lever to determine ground speed.

**Forward**—one of six speeds. Position number one (1) is the slowest. Position number six (6) is the fastest.

**Reverse**—two reverse (R) speeds. “R” closest to the operator (all the way back) is the faster of the two.

## AUGER DRIVE (See figure 11)

The auger drive clutch is located on the left handle. Squeeze the clutch grip to engage the augers. Release to stop the snow throwing action. (Traction drive clutch must also be released.)

## TRACTION DRIVE/AUGER CLUTCH LOCK

(See figure 11)

The traction drive clutch is located on the right handle. Squeeze the traction drive clutch to engage the wheel drive. Release to stop.

This same lever also locks the auger clutch so you can turn the chute crank without interrupting the snow throwing process. If the auger drive clutch is engaged with the traction drive clutch engaged, the operator can release the auger drive clutch (on the left handle) and the augers will remain engaged. Release the traction drive clutch to stop both the augers and wheel drive (auger drive clutch must also be released).



FIGURE 12.

## CHUTE CRANK (See figure 11)

The chute crank is located on left hand side of the snow thrower.

To change the direction in which snow is thrown, turn chute crank as follows:

1. Crank clockwise to discharge to the left.
2. Crank counterclockwise to discharge to the right.

## CHUTE TILT CONTROL (See figure 11)

**Models 646F and 666H only:** The distance snow is thrown can be adjusted by adjusting the angle of the chute assembly. Move the chute tilt control forward to decrease the distance, toward the rear to increase.

**Model 616E only:** To adjust chute assembly, loosen the hand knob. Pivot the top of the chute assembly to position desired. Retighten the hand knob. The sharper the angle, the shorter the distance snow is thrown.

## THROTTLE CONTROL (See figure 13)

The throttle control is located on the engine. It regulates the speed of the engine.

## SAFETY IGNITION SWITCH (See figure 13)

The ignition key must be inserted in the switch before the unit will start. Remove the ignition key when snow thrower is not in use.




FIGURE 13.—Model 646F Shown



# OPERATION

## GAS AND OIL FILL-UP

Service the engine with gasoline and oil as instructed in the separate engine manual packed with your snow thrower. **Read instructions carefully.**

**NOTE:** Your snow thrower is shipped without oil; however, a small amount of oil may be present from the factory. Do not overfill.



**WARNING:** Never fill fuel tank indoors, with engine running or while engine is hot. Do not smoke when filling fuel tank.

## ELECTRIC STARTER (Optional)

**WARNING:** The optional electric starter is equipped with a three-wire power cord and plug, and is designed to operate on 120 volt AC household current. It must be properly grounded at all times to avoid the possibility of electric shock which may be injurious to the operator. Follow all instructions carefully. Determine that your house wiring is a three-wire grounded system. Ask a licensed electrician if you are not certain. If your house wiring system is not a three-wire grounded system, do not use this electric starter under any conditions. If your system is grounded and a three-hole receptacle is not available at the point your starter will normally be used, one should be installed by a licensed electrician.

When connecting the power cord, always connect cord to starter on engine first, then plug the other end into a three-hole grounded receptacle.

When disconnecting the power cord, always unplug the end from the three-hole grounded receptacle first.

## TO START ENGINE

**IMPORTANT:** If unit shows any sign of motion (drive or augers) with the clutch grips disengaged, shut engine off immediately. Readjust as instructed in the "Final Adjustments" section of the Assembly Instructions.

**NOTE: Models 646F and 666H only:** Your snow thrower is equipped with a headlight. The headlight will be on when the engine is running.

1. Attach spark plug wire to spark plug.
2. **Make certain the auger drive and traction drive clutch grips are in the disengaged (released) position.**
3. Move throttle control up to FAST position. Insert ignition key into slot. See figure 13. Be certain it snaps into place. **Do not** turn key.

4. Rotate choke knob to FULL choke position (cold engine start).

If engine is warm, place choke in OFF position instead of FULL.

5. **Electric Start Only (Optional):** Connect power cord to switch box on engine. Plug the other end of power cord into a three-hole, grounded 120 volt AC receptacle.
6. Push primer button two or three times. See figure 13.

If engine is warm, push primer button once only.

**NOTE:** Always cover vent hole in primer button when pushing. Additional priming may be necessary for first start if temperature is below 15°F.

7. **Recoil Start:** Grasp starter handle (see figure 13) and pull rope out slowly, until it pulls slightly harder. Let rope rewind slowly. Pull starter handle rapidly. Do not allow handle to snap back. Allow it to rewind slowly while keeping a firm hold on the starter handle.

**Electric Start (Optional):** Push starter button on top of the engine to crank the engine. When engine starts, release starter button.

8. Repeat step 7 until engine starts. If engine fails to start, repeat steps 6 and 7 until engine starts.
9. As engine warms up and begins to operate evenly, rotate choke knob slowly to OFF position. If engine falters, return to FULL choke, then slowly move to OFF position.



## TO STOP ENGINE

1. Run engine for a few minutes before stopping to help dry off any moisture on the engine.
2. To help prevent possible freeze-up of starter, proceed as follows.

**Optional Electric Starter:** Connect power cord to switch box on engine, then to 120 volt AC receptacle. With the engine running, push starter button and spin the starter for several seconds. The unusual sound made by spinning the starter will not harm engine or starter. Disconnect the power cord from receptacle first, and then from switch box.

**Recoil Starter:** With engine running, pull starter rope with a rapid, continuous full arm stroke three or four times. Pulling the starter rope will produce a loud clattering sound, which is not harmful to the engine or starter.

3. To stop engine, remove the ignition key. **Do not** turn key. Disconnect the spark plug wire from the spark plug to prevent accidental starting while equipment is unattended.

**NOTE:** Do not lose ignition key. Keep it in a safe place. Engine will not start without the ignition key.

4. Wipe all snow and moisture from the carburetor cover in the area of the control levers. Also, move control levers back and forth several times. Leave throttle control lever in the STOP or OFF position. Leave choke control in the FULL choke position.



## TO ENGAGE DRIVE

1. With the engine running near top speed, move shift lever into one of the six FORWARD positions or two REVERSE positions. Select a speed appropriate for the snow conditions that exist. Use the slower speeds until you are familiar with the operation of the snow thrower.
2. Squeeze the traction drive clutch grip against the right handle and the snow thrower will move. Release it and the drive motion will stop.

**NOTE:** NEVER move shift lever without first releasing the drive clutch.

## TIRE CHAINS (Optional Equipment)

Tire chains should be used whenever extra traction is needed.

## OPERATING TIPS

**NOTE:** Allow the engine to warm up for a few minutes as the engine will not develop full power until it reaches operating temperature.



**WARNING:** Temperature of muffler and surrounding areas may exceed 150°F. Avoid these areas.

1. For most efficient snow removal, remove snow immediately after it falls.
2. Discharge snow downwind whenever possible. Slightly overlap each previous swath.
3. Set the skid shoes 1/4" below the scraper bar for normal usage. The skid shoes may be adjusted upward for hard-packed snow. Adjust downward when using on gravel or crushed rock.
4. Be certain to follow the precautions listed under "To Stop Engine" on page 9 to prevent possible freeze-up.
5. Clean the snow thrower thoroughly after each use.

## ADJUSTMENTS



**WARNING:** NEVER attempt to clean chute or make any adjustments while engine is running.

### CHUTE ASSEMBLY ADJUSTMENT

The distance snow is thrown can be adjusted by adjusting the angle of the chute assembly. Refer to the Control section of this manual.

### SKID SHOE ADJUSTMENT

The space between the shave plate and the ground can be adjusted. Refer to page 7 of the Assembly Instructions.

### TRACTION DRIVE CLUTCH ADJUSTMENT

Refer to the Final Adjustment section of the Assembly Instructions to adjust the traction drive clutch. If you are uncertain that you have reached the correct adjustment, the adjustment can be physically checked as follows.

With the snow thrower tipped forward (be certain to drain the gasoline or place plastic film under the gas cap if the snow thrower has already been operated), remove the frame cover underneath the snow thrower by removing six self-tapping screws.

With the traction drive clutch released, there must be clearance between the friction wheel and the drive plate in all positions of the shift lever. With the traction drive clutched engaged, the friction wheel must contact the drive plate. See figure 14.

If adjustment is necessary, loosen the lock nut on the traction drive cable and thread the cable in or out as necessary. Tighten the lock nut to secure the cable when correct adjustment is reached. Reassemble the frame cover.

**NOTE:** If you placed plastic under the gas cap, be certain to remove it.




FIGURE 14.

### AUGER CLUTCH ADJUSTMENT

To adjust the auger clutch, refer to Final Adjustment section of Assembly Instructions.

### SHIFT ROD ADJUSTMENT

To adjust the shift rod, remove the hairpin clip and flat washer which secure the shift rod to the shift arm assembly. Refer to figure 8. Adjust as specified in Assembly Instructions.

### CARBURETOR ADJUSTMENT



**WARNING:** If any adjustments are made to the engine while the engine is running (e.g. carburetor), keep clear of all moving parts. Be careful of heated surfaces and muffler.

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude and load.

Refer to the separate engine manual packed with your unit for carburetor adjustment information.

### DRIVE WHEELS

The wheels may be adjusted for two different methods of operation. The adjustment is made by placing the click pins in one of two different holes on the right side of the unit. See figure 15.

1. **One Wheel Driving**—Place click pin in the outside axle hole on the right side. This position gives power drive to the left wheel only, making the unit easier to maneuver.
2. **Both Wheels Driving**—Place click pin in the hole in the hub next to the rim on the right side. This position is good for heavy snow as there is power drive in both wheels.




FIGURE 15.

## MAINTENANCE



**WARNING:** Disconnect the spark plug wire and ground against the engine before performing any repairs or maintenance.

### LUBRICATION

#### Gear Shaft

Lubricate the gear shaft with "Slick 50 Grease" at least once a season or after every 25 hours of operation (available at automotive stores, or order part number 737-0290). Refer to figure 14.

**IMPORTANT:** Keep all grease and oil off of the friction wheel and drive plate.

#### Shifting Mechanism

Lubricate the shifting mechanism and pivot points on the shift rod with engine oil at least once a season or after every 25 hours of operation.

#### Traction Drive/Auger Clutch Lock

The cams on the ends of the control rods which interlock the traction drive and auger drive clutches must be lubricated at least once a season or every twenty-five hours of operation. The cams can be accessed beneath the handle panel. Use a multi-purpose automotive grease.

#### Gear Case

The gear case is lubricated with grease at the factory and does not require checking. If disassembled for any reason, lubricate with 2 ounces of Shell Alvania grease, part number 737-0168.

#### Bearings

Lubricate the auger and wheel bearings once a season with light oil.

## AUGERS

The augers are secured to the spiral shaft with two hex bolts and hex lock nuts. See figure 16. If you hit a foreign object or ice jam, the snow thrower is designed so that the hex bolts will shear.

If the augers will not turn, check to see if the hex bolts have sheared. Two replacement hex bolts and hex lock nuts have been provided with the snow thrower. For future use, order part number 710-0890 (hex bolt 5/16-18 x 1.5" long) and 712-0158 (hex lock nut 5/16-18 thread).




FIGURE 16.

## SHAVE PLATE AND SKID SHOES

The shave plate and skid shoes on the bottom of the snow thrower are subject to wear. They should be checked periodically and replaced when necessary.

To remove skid shoes, remove the four carriage bolts, belleville washers and hex nuts which attach them to the snow thrower. Reassemble new skid shoes with the four carriage bolts, belleville washers (cupped side goes against skid shoes) and hex nuts. Make certain the skid shoes are adjusted to be level.

To remove shave plate, remove the carriage bolts, belleville washers and hex nuts which attach it to the snow thrower housing. Reassemble new shave plate, making sure heads of the carriage bolts are to the inside of the housing. Tighten securely.

## ENGINE

Refer to separate engine manual for all engine maintenance procedures.

## BELT REMOVAL AND REPLACEMENT



**WARNING:** Disconnect the spark plug wire from the spark plug and ground.

### AUGER BELTS

**NOTE:** It is necessary to remove both belts in order to change either one. If changing just one belt, be certain to check the condition of the other belt (model 616E has only one auger belt).

1. Remove the plastic belt cover on the front of the engine by removing the two self-tapping screws. See figure 17.




FIGURE 17.

2. Drain the gasoline from the snow thrower, or place a piece of plastic under the gas cap.
3. Tip the snow thrower up and forward so that it rests on the housing.
4. Remove six self-tapping screws from the frame cover underneath the snow thrower.
5. Roll the front and rear auger belts off the engine pulley. See figure 18.




FIGURE 18.

6. Unhook the idler spring from the hex bolt on the auger housing. See figure 19.
7. Unhook the support bracket spring from the frame.
8. Lift the front auger belt from the auger pulley, and slip belt between the support bracket and the auger pulley. See figure 19. Repeat this step for rear auger belt (except Model 616E).
9. Replace both auger drive belts by following instructions in reverse order.




FIGURE 19.

#### DRIVE BELT

1. Follow steps 1 through 4 of previous instructions.
2. Pull idler pulley up, and lift belt off engine pulley and friction wheel disc. See figure 18.
3. Using a 7/16" wrench, loosen the nut on the stop bolt until the support bracket rests on the auger pulley. See figure 20.
4. Slip belt between friction wheel and friction wheel disc. See figure 20. Remove and replace belt. Reassemble following the instructions in reverse order.

**NOTE:** The support bracket must rest on the stop bolt after the new belt has been assembled. See figure 20.




FIGURE 20.

#### CHANGING THE FRICTION WHEEL RUBBER

The rubber on the friction wheel is subject to wear and should be checked after 25 hours of operation, and periodically thereafter. Replace the friction wheel rubber if any signs of wear or cracking are found.

1. Drain the gasoline from the snow thrower, or place a piece of plastic under the gas cap.
2. Tip the snow thrower up and forward, so that it rests on the housing.
3. Remove six self-tapping screws from the frame cover underneath the snow thrower.
4. Remove the click pins which secure the wheels, and remove the wheels from the axle.
5. Remove the gear shaft from the unit by removing the bolts, lock washers and flat washers from each side of the frame. See figure 21. Hold the friction wheel assembly, and slide the gear shaft out of the unit toward the right hand side. Refer to figure 14.
6. Remove the six screws from the friction wheel assembly (three from each side). Remove the friction wheel rubber from between the friction wheel plate.
7. Reassemble new friction wheel rubber to the friction wheel assembly, tightening the six screws in rotation and with equal force.
8. Slide the friction wheel assembly up onto the shift mechanism as shown in figure 14, and slide the gear shaft back into the unit. Reassemble in reverse order.




FIGURE 21.

## OFF-SEASON STORAGE



**WARNING:** Never store engine with fuel in tank indoors or in poorly ventilated areas, where fuel fumes may reach an open flame, spark or pilot light as on a furnace, water heater, clothes dryer or other gas appliance.

If unit is to be stored over 30 days, prepare for storage as follows:

1. Remove all gasoline from carburetor and fuel tank to prevent gum deposits from forming on these parts and causing possible malfunction of engine.
  - a. Run engine until fuel tank is empty and engine stops due to lack of fuel.
  - b. Drain carburetor by pressing upward on bowl drain, located below the carburetor cover.



**WARNING:** Drain fuel into approved container outdoors, away from open flame. Be certain engine is cool. Do not smoke.

Fuel left in engine during warm weather deteriorates and will cause serious starting problems.

**NOTE:** Fuel stabilizer (such as STA-BIL) is an acceptable alternative in minimizing the formation of fuel gum deposits during storage. Add stabilizer to gasoline in fuel tank or storage container. Always follow mix ratio found on stabilizer container. Run engine at least 10 minutes after adding stabilizer to allow it to reach carburetor. Do not drain carburetor if using fuel stabilizer.

2. Remove spark plug and pour one (1) ounce of engine oil through spark plug hole into cylinder. Crank engine several times to distribute oil. Replace spark plug.
3. Remove all dirt from exterior of engine and equipment.
4. Follow lubrication recommendations on page 11.


**NOTE:** When storing any type of power equipment in an unventilated or metal storage shed, care should be taken to rust proof the equipment. Using a light oil or silicone, coat the equipment, especially any chains, springs, bearings and cables.

# TROUBLE SHOOTING GUIDE

Trouble	Possible Cause(s)	Corrective Action
Engine fails to start	<ol style="list-style-type: none"> <li>1. Fuel tank empty, or stale fuel.</li> <li>2. Blocked fuel line.</li> <li>3. Key not in switch on engine.</li> <li>4. Spark plug wire disconnected.</li> <li>5. Faulty spark plug.</li> </ol>	<ol style="list-style-type: none"> <li>1. Fill tank with clean, fresh gasoline.</li> <li>2. Clean fuel line.</li> <li>3. Insert key.</li> <li>4. Connect wire to spark plug.</li> <li>5. Clean, adjust gap or replace.</li> </ol>
Engine runs erratic	<ol style="list-style-type: none"> <li>1. Unit running on CHOKE.</li> <li>2. Blocked fuel line or stale fuel.</li> <li>3. Water or dirt in fuel system.</li> <li>4. Carburetor out of adjustment.</li> </ol>	<ol style="list-style-type: none"> <li>1. Turn choke knob to OFF position.</li> <li>2. Clean fuel line; fill tank with clean fresh gasoline.</li> <li>3. Use carburetor bowl drain to drain fuel tank. Refill with fresh fuel.</li> <li>4. Adjust carburetor. See separate engine manual.</li> </ol>
Loss of power	<ol style="list-style-type: none"> <li>1. Spark plug wire loose.</li> <li>2. Gas cap vent hole plugged.</li> </ol>	<ol style="list-style-type: none"> <li>1. Connect and tighten spark plug wire.</li> <li>2. Remove ice and snow from cap. Be certain vent hole is clear.</li> </ol>
Engine overheats	<ol style="list-style-type: none"> <li>1. Engine oil level low.</li> <li>2. Carburetor not adjusted properly.</li> </ol>	<ol style="list-style-type: none"> <li>1. Fill crankcase with proper oil.</li> <li>2. Adjust carburetor. See separate engine manual.</li> </ol>
Excessive vibration	Loose parts or damaged impeller.	Stop engine immediately and disconnect spark plug wire. Tighten all bolts and nuts. Make all necessary repairs. If vibration continues, have unit serviced by authorized service dealer.
Hard to shift, or will not shift	Shift rod misadjusted.	Readjust shift rod. See Adjustment section of this manual.
Unit fails to propel itself	<ol style="list-style-type: none"> <li>1. Incorrect adjustment of drive clutch.</li> <li>2. Drive belt loose or damaged.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust drive clutch. Refer to Adjustment section.</li> <li>2. Replace drive belt. Refer to Maintenance section.</li> </ol>
Unit fails to discharge snow	<ol style="list-style-type: none"> <li>1. Auger shear bolt broken.</li> <li>2. Discharge chute clogged.</li> <li>3. Foreign object lodged in auger.</li> <li>4. Incorrect adjustment of auger drive clutch.</li> <li>5. Auger drive belt loose or damaged.</li> </ol>	<ol style="list-style-type: none"> <li>1. Replace auger shear bolt. Refer to Maintenance section.</li> <li>2. Stop engine immediately and disconnect spark plug wire. Clean discharge chute and inside of auger housing.</li> <li>3. Stop engine immediately and disconnect spark plug wire. Remove object from auger.</li> <li>4. Adjust auger clutch. Refer to Adjustment section.</li> <li>5. Replace auger drive belt. Refer to Maintenance section.</li> </ol>

NOTE: For repairs beyond the minor adjustments listed above, please contact your nearest authorized service dealer.

# Models 616E, 646F and 666H





# Models 616E, 646F and 666H

## PARTS LIST FOR MODELS 616E, 646F AND 666H SNOW THROWERS


REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	725-1646		Lamp Housing w/Lens†	33	746-0898		Drive Clutch Cable
2	710-0351		Truss Mach. B-Tap Scr. #10 x .5	34	747-0798		Shift Rod
3	710-0776A		Hex AB-Tap Scr. 1/4 x .62" Lg.†	35	720-0232		Shift Knob
4	736-0242		Bell-Wash. .325" I.D. x .88" O.D.	36	784-0297		Shift Handle
5	748-0362		Cam Handle Lock	37	784-5679		Handle Brkt.—L.H.
6	714-0507		Cotter Pin 3/32" Dia. x .75" Lg.	38	784-5680		Handle Brkt.—R.H.
7	736-0509		Washer (Special) .72" O.D.	40	736-0264		FI-Wash. .344" I.D. x .62" O.D.
8	784-5681		Handle Support Brkt.—L.H.	41	714-0104		Internal Cotter Pin 5/16" Dia.
9	784-5682		Handle Support Brkt.—R.H.	42	711-0677		Ferrule
10	732-0145		Compression Spring	43	710-0538		Hex Bolt 5/16-18 x .62" Lg.
11	726-0321		Retaining Clip†				(Special)
13	749-0908		Handle—R.H.	44	710-3180		Hex Bolt 5/16-18 x 1.75" Lg.
14	749-0909		Handle—L.H.				(Gr. 5)
15	712-0271		Hex Sems Nut 1/4-20 Thd.†	45	784-5599		Handle Tab
16	684-0036		Engagement Handle—R.H.	46	710-1250		Curved Carr. Bolt 5/16-18 x 1.5" Lg.
17	684-0037		Engagement Handle—L.H.				
18	748-0363		Pawl Handle Lock	47	731-1334		Handle Panel (616E—Not Shown)
19	747-0877		Rod Cam		731-1347		Handle Panel†
20	684-0032A		Handle Panel Support†	48	731-1313		Cable Guide†
	684-0033A		Handle Panel Support (616E—Not Shown)	49	746-0896		Chute Control Cable†
21	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.	50	746-0901		Chute Control Cable w/Clip†
22	711-0946		Clevis Pin .437" Dia. x .65" Lg.	51	736-0425		Bell-Wash. .325" I.D. x .93" O.D.†
23	712-0116		Hex Ins. L-Nut 3/8-24 Thd.	52	784-5604		Chute Tilt Handle†
24	712-0267		Hex Nut 5/16-18 Thd.*	53	712-0158		Hex Cent. L-Nut 5/16-18 Thd.†
25	712-0287		Hex Nut 1/4-20 Thd.*	57	712-0267		Hex Nut 5/16-18 Thd.
26	714-0111		Cotter Pin 3/32" Dia. x 1" Lg.	58	736-0271		Spr. Wash. .32" I.D. x .62" O.D.
27	732-0193		Compression Spring	59	712-0121		Hex Nut #10-24 Thd. (Incl. w/Ref. 32 & 33)
28	735-0199A		Rubber Bumper	60	725-0157		Cable Tie†
29	736-0105		Bell-Wash. .38" I.D. x .88" O.D.	61	736-0506		Washer (Special) 1.25" O.D.†
30	736-0119		L-Wash. 5/16" I.D.*	62	710-0252		Hex Bolt 1/4-20 x .85" Lg.*
31	736-0175		Spring Wash. .265" I.D.	63	736-0270		Bell-Wash. .265" I.D. x .75" O.D.
32	746-0897		Auger Clutch Cable	64	725-1645		Bulb†
				65	629-0059		Wire Harness†

†Model 646F and 666H Only.

### LABELS

MODELS	TYPE	DESCRIPTION	PART NO.
616E (500)	Instruction	Right Control Panel	777-0932
		Left Control Panel w/o Chute	777-0934
	Decorative	Axle Pin Label	777-8160
		Snow Boss 500	777-2377
		Handle Panel w/o Lights	777-2393
646F (850)	Instruction	Handle Panel Center	777-0873
		Right Control Panel	777-0932
	Decorative	Left Control Panel	777-0933
		Snow Boss 850	777-2379
		Handle Panel with Lights	777-2382
		8 HP Snow Thrower Engine	777-2436
666H (1050)	Instruction	Handle Panel Center	777-0873
		Right Control Panel	777-0932
	Decorative	Left Control Panel	777-0933
		Snow Boss 1050	777-2381
		Handle Panel with Lights	777-2382
		10 HP Snow Thrower Engine	777-2438
All Models	Danger	Warning Auger Top of Chute	777-0783 777-2361 777-8088B

# Models 616E, 646F and 666H




# Models 616E, 646F and 666H

## PARTS LIST FOR MODELS 616E, 646F AND 666H SNOW THROWERS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	618-0120		Worm Drive Ass'y. Comp. (616E)	47	710-1087		Hex Bolt 5/16-18 x 5/8" Lg.
	618-0121		Worm Drive Ass'y. Comp. (646F)	50	741-0309		Ball Bearing .75" I.D.
	618-0122		Auger Gear Box Ass'y. (666H)	51	705-5187A		Blower Fan Ass'y.
2	719-0292		Reducer Housing—L.H.	52	715-0114		Spiral Pin 1.5" Lg.
3	721-0179		Oil Seal	53	710-0890		Shear Bolt 5/16-18 x 1.5" Lg.
4	741-0339		Flange Bearing .75" I.D.	54	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
5	719-0293		Reducer Housing—R.H.	55	736-0188		FI-Wash. .76" I.D. x 1.49"
6	737-3000		Grease Fitting	56	741-0493A		Flange Bushing .8" I.D.
7	710-0642		Hex TT-Tap Scr. 1/4-20 x .75" Lg.	57	684-0022		Chute Crank Ass'y.
8	711-0908		24" Auger Shaft (616E)	59	712-0429		Hex Ins. L-Nut 5/16-18 Thd.
	711-0909		26" Auger Shaft (646F)	60	714-0507		Cotter Pin 3/32" Dia. x .75"
	711-1024	N	30" Auger Shaft (666H)	61	715-0138		Roll Pin 1/8" Dia. x .63" Lg.
9	714-0388		#61 Hi-Pro Key 3/16" x 5/8" Dia.	62	720-0201A		Chute Crank Knob
10	715-0143		Spiral Pin 1.25" Lg.	63	726-0100		Push Nut
11	717-0526		Impeller Shaft	64	705-5189		Spiral Ass'y.—L.H. (616E)
12	717-0528		Worm Gear		705-5188		Spiral Ass'y.—R.H. (616E— Not Shown)
13	718-0186		Thrust Collar				Spiral Ass'y.—L.H. (646F)
14	721-0327		Oil Seal		705-5193		Spiral Ass'y.—R.H. (646F— Not Shown)
15	736-0351		FI-Wash. .76" I.D. x 1.5" O.D.		705-5192		Spiral Ass'y.—L.H. (666H)
16	736-0369		FI-Wash. .5" I.D. x 1" O.D.			N	Spiral Ass'y.—R.H. (666H— Not Shown)
17	736-0445		FI-Wash. .76" I.D. x 1.49" O.D.		705-5249		
19	741-0376		Flange Bearing .75" I.D.		705-5248	N	
20	748-0108		Flange Bearing .503" I.D.				
21	684-0039A		24" Auger Housing Ass'y. (616E)	65	736-0140		FI-Wash. .385" I.D. x .62" O.D.
	684-0040A		26" Auger Housing Ass'y. (646F)	67	784-5678		Upper Chute Crank Brkt.
	684-0055	N	30" Auger Housing Ass'y. (666H)	68	784-5647		Lower Chute Crank Brkt.
22	710-0157		Hex Bolt 5/16-24 x .75" Lg.*	69	741-0475		Plastic Bushing .38" I.D.
23	710-0260		Carriage Bolt 5/16-18 x .62" Lg.	70	05845A		Bearing Housing
24	710-0451		Carriage Bolt 5/16-18 x .75" Lg.	75	741-0300		Plastic Bearing w/Flats
25	712-0123		Hex Nut 5/16-24 Thd.*	76	05931		Bearing Housing
26	712-0267		Hex Nut 5/16-18 Thd.*	77	731-0851		Chute Flange Keeper
27	736-0119		L-Wash. 5/16" I.D.*	78	720-0241		Knob (616E)
28	736-0242		Bell-Wash. .345" I.D. x .88" O.D.	79	710-0262		Carriage Bolt 5/16-18 x 1.5" Lg.
29	784-5580		Slide Shoe	82	712-0107		Hex L-Nut 1/4-20 Thd.
30	784-5581		24" Shave Plate (616E)	83	731-0921		Upper Chute (616E)
	784-5579		26" Shave Plate (646F)		731-1320		Upper Chute (646F & 666H)
	784-5575	N	30" Shave Plate (666H)	84	731-1300A	N	Lower Chute
31	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.	85	736-0231		FI-Wash. .344" I.D. x 1.125"
32	712-0287		Hex Nut 1/4-20 Thd.*	86	710-0255		Truss Mach. Scr. 1/4-20 x .75" Lg.
33	731-1379		Chute Adapter				
34	736-0175		Spring Washer 1/4" I.D.	87	736-0142		FI-Wash. 1/4" I.D.
35	710-0459		Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)	88	710-0776A		Hex AB-Tap Scr. 1/4 x .62" Lg. (646F)
36	710-0812		Hex Bolt 1/4-20 x .75" Lg. (Gr. 5)				Cable Guide (646F & 666H)
37	712-0116		Hex Ins. L-Nut 3/8-24 Thd.	89	731-1313		Cable Bracket (646F & 666H)
38	712-0181		Hex Top L-Nut 3/8-16 Thd.	90	784-5594		Chute Control Cable (646F & 666H)
40	712-0291		Hex L-Nut 1/4-20 Thd.	91	746-0896		Chute Control Cable w/Clip (646F)
41	732-0611		Ext. Spring 3.6" Lg.				
42	736-0167		FI-Wash. 5/8" I.D. x 1.25"	92	746-0901		Hex Bolt 5/16-18 x 1.5" Lg.
43	736-0329		L-Wash. 1/4" I.D.*				Chute Reinforcement
44	738-0281		Shld. Bolt .625" Dia. x .170" Lg.	95	710-0442		
45	756-0178		FI-Idler 2.75" O.D.	96	705-5225		
46	784-5632		Auger Idler Brkt.	97	721-0325		Plug

\*For faster service obtain standard nuts, bolts and washers locally.  
If these items cannot be obtained locally, order by part number  
and size as shown on parts list.

# Models 616E, 646F and 666H




# Models 616E, 646F and 666H

## PARTS LIST FOR MODELS 616E, 646F AND 666H SNOW THROWERS

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	—		Engine**	29	736-0242		Bell-Wash. .345" I.D. x .88" O.D.
2	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.	30	736-0505		FI-Wash. .34" I.D. x 1.5" O.D.
3	731-1324		Belt Cover	31	736-0507		Brg. Retaining Washer (616E Only)
4	714-0133		Sq.-Key 3/16 x 1.5" Lg. (646F & 666H)	32	756-0967		Auger Pulley
	714-0122		Sq.-Key 3/16 x .75" Lg. (616E)	33	710-0696		Hex Bolt 3/8-24 x .88" Lg.
5	710-3166		Hex Patch Bolt 5/16-24 x 1" Lg. (Gr. 5)	34	736-0331		Bell-Wash. .39" I.D. x 1.13" O.D.
6	656-0009		Friction Wheel Disc Ass'y.	35	736-0247		FI-Wash. .406" I.D. x 1.25" O.D.
7	710-0342		Hex Bolt 3/8-16 x 1.25" Lg.	36	748-0360		Adapter Pulley
8	756-0313		FI-Idler 2.12" O.D.	37	756-0178		FI-Idler 2.75" O.D.
9	732-0264		Ext. Spring 2.5" Lg.	38	712-0116		Hex Ins. L-Nut 3/8-24 Thd.
10	712-0181		Hex Top L-Nut 3/8-16 Thd.	39	710-0459		Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
11	710-0230		Hex Bolt 1/4-28 x .5" Lg.	40	738-0281		Shld. Bolt .625" Dia. x .170" Lg.
12	736-0329		L-Wash. 1/4" I.D.*	41	784-5632		Auger Idler Brkt.
13	684-0021		Friction Wheel Support Brkt. Ass'y.	42	736-0174		Wave Wash. .66" I.D. x .88"
14	712-0711		Hex Jam Nut 3/8-24 Thd.	43	732-0611		Ext. Spring 3.6" Lg.
15	736-0105		Bell-Wash. .38" I.D. x .88" O.D.	44	710-0812		Hex Bolt 1/4-20 x .75" Lg. (Gr. 5)
16	714-0474		Cotter Pin 1/8" x .75" Lg.	45	712-0287		Hex Nut 1/4-20 Thd.*
17	736-0160		FI-Wash. .531" I.D. x .93" O.D.	46	712-0291		Hex L-Nut 1/4-20 Thd.
18	748-0190		Spacer .508" I.D. x .75" O.D.	47	710-1017		Torx Mach. AB-Tap Scr. 1/4 x .62" Lg.
19	05896A		Drive Clutch Idler Bracket	48	784-5658		Front Support Brkt. Guide
20	748-0234		Shld. Spacer .5" Dia. x .27" Lg.	49	710-0502		Hex L-Wash. TT-Tap Scr. 3/8-16 x 1.25" Lg.
22	710-0117		Hex Bolt 5/16-24 x 1" Lg.(616E)	50	738-0870		Shld. Bolt 5/16" Dia. x .35" Lg.
	710-0604		Hex Wash. Hd. Tap Scr. 5/16-18 x .62" Lg. (646F & 666H)	51	712-0298		Hex Jam Nut 1/4-20 Thd.
23	754-0343		"V"-Belt (616E)	52	710-0788		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x 1" Lg.
	754-0346		"V"-Belt (646F & 666H)	53	710-0602		Hex Wash. Hd. Tap Scr. 5/16-18 x 1" Lg. (646F & 666H)
24	732-0339		Extension Spring (616E)	54	736-0159		FI-Wash. .349" I.D. x .879" O.D. (646F & 666H)
	732-0710		Extension Spring (646F & 666H)	55	732-0705		Cable Control Wire (646F & 666H)
25	756-0959		2" Dia. Pulley				
26	756-0569		3/8 "V"-Pulley Half				
27	754-0431		"V"-Belt (616E)				
	754-0430		"V"-Belt (646F & 666H) (2 Req'd.)				
28	710-0627		Hex Cap L-Bolt 5/16-24 x .75" Lg.				

\*\*Extension Cord—3-Prong for 110V Electric Starter.  
Part Number 629-0071.

# Models 616E, 646F and 666H



**PARTS LIST FOR MODELS 616E, 646F AND 666H SNOW THROWERS**

REF. NO.	PART NO.	CODE	DESCRIPTION	REF. NO.	PART NO.	CODE	DESCRIPTION
1	684-0042		Friction Wheel Ass'y. Comp.	26	734-0255		Air Valve
1A	618-0063		Friction Wheel Brg. Ass'y.	27	734-1527		Tire Only (616E)
2	684-0008		Shift Arm Ass'y.		734-1530		Tire Only (646F)
3	684-0013		Shift Rod Ass'y.		734-1525		Tire Only (666H)
4	684-0030		Frame Ass'y.	28	734-1713		Rim Only (616E)
5	710-0642		Hex TT-Tap Scr. 1/4-20 x .75" Lg.		734-1708		Rim Only (646F)
6	710-0653		Hex Tap Scr. 1/4-20 x .38" Lg.		734-1711		Rim Only (666H)
7	710-0788		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x 1" Lg.	29	741-0401		Sleeve Bearing .752" I.D.
8	710-1017		Torx Mach. AB-Tap Scr. 1/4 x .62" Lg.	30	714-0126		#9 Hi-Pro Key 3/16" x 3/4" Dia.
10	712-0287		Hex Nut 1/4-20 Thd.*	31	714-0162		Cotter Pin 5/32" x 1-1/4" Lg.
11	712-0298		Hex Jam Nut 1/4-20 Thd.	32	714-0143		Klik Pin
12	717-1415A	N	Gear Shaft	33	717-1414		79 Tooth Gear
14	736-0176		FI-Wash. .265" I.D. x .938" O.D.	34	736-0188		FI-Wash. .76" I.D. x 1.49" O.D.
15	736-0329		L-Wash. 1/4" I.D.*	35	738-0869		Wheel Axle (616E)
16	738-0870		Shld. Bolt 5/16 Dia. x .35" Lg.	36	741-0598		Hex Flange Brg. .752" I.D.
17	741-0563		Ball Brg. w/Snap Ring	38	738-0830		Wheel Axle (646F & 666H)
18	756-0625		Cable Roller Guide	40	710-0502A		Hex Bolt 3/8-16 x 1.25"
19	784-5590		Shift Bracket—Frame	41	715-0249		Spr. Roll Pin 1.12" Lg.
20	784-5638		Frame Cover	42	736-3052		FI-Wash. .406" I.D. x 1" O.D.
21	784-5644		Drive Cable Guide Brkt.	43	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
22	784-5646		Auger Cable Guide Brkt.	44	718-0240		Friction Wheel Hub
23	784-5658		Front Support Brkt. Guide	45	784-5677		Friction Plate
25	734-1714		Wheel Ass'y. Comp. (616E)	46	735-0243		Friction Wheel Rubber
	734-1709		Wheel Ass'y. Comp. (646F)	47	710-3007		Hex Wash. Tap Scr. 3/8" Lg.
	734-1712		Wheel Ass'y. Comp. (666H)				

## THE WHITE OUTDOOR PRODUCTS CUSTOMER CARE TWO YEAR LIMITED WARRANTY

For two years from the date of retail purchase within the United States of America, its possessions and territories, White Outdoor Products Company will, at its option, repair or replace, for the original purchaser free of charge, any part or parts found to be defective in material or workmanship. This warranty covers units which have been operated and maintained in accordance with the owner's instructions furnished with the unit, and which have not been subject to misuse, abuse, neglect, accident, improper maintenance or alteration.

Normal wear parts or components thereof are subject to separate terms as noted below in the "no fault ninety day consumer warranty" clause. Commercial use is subject to the terms listed above, and is covered for a period of 90 days from the date of purchase.

**TWO YEAR CONSUMER WARRANTY ON NORMAL WEAR PARTS WITH NINETY DAY NO FAULT PROTECTION:** All normal wear part failures will be covered on this product for a period of ninety days regardless of cause. After ninety days but within the two-year warranty period, normal wear parts failures will be covered if caused by defects in material or workmanship of other component parts. Normal wear parts are defined as belts, blades, blade adapters, grass bags, rider deck wheels and seat.

**HOW TO OBTAIN SERVICE:** warranty service is available, with proof of purchase, through your local authorized service dealer. To locate the dealer in your area, please check the Yellow Pages or contact the customer service department of White Outdoor Products Company, PO Box 361131, Cleveland, Ohio, 44136-0019, phone (216)225-8883. The return of a complete unit will not be accepted by the factory unless prior written permission has been extended by the service department of White Outdoor Products Company.

**TRANSPORTATION CHARGES:** transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by White Outdoor Products Company.

**UNITS EXPORTED OUT OF THE UNITED STATES:** White Outdoor Products Company does not extend any warranty for products sold or exported outside of the United States of America, its possessions and territories, except those sold through White Outdoor Products.

### OTHER WARRANTIES:

1. The engine or component parts thereof carry separate warranties from their manufacturers. Please refer to the applicable manufacturer's warranty on these items.
2. Log splitter pumps, valves and cylinders or component parts thereof are covered by a one year warranty.
3. Batteries are covered by a 90 day replacement warranty.
4. All other warranties, express or implied, including any implied warranty of merchantability or fitness for a particular purpose are hereby expressly disclaimed in their entirety.
5. The provisions as set forth in this warranty provide the sole and exclusive remedy of White Outdoor Products Company's obligations arising from the sales of its products. White Outdoor Products Company will not be liable for incidental or consequential loss or damage.

**HOW THE STATES LAW RELATES TO THIS WARRANTY:** this limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Certain disclaimers are not allowed in some states and therefore they may not apply to you under all circumstances.

Note: this warranty does not cover routine maintenance items such as lubricants, filters, blade sharpening and tune-ups, or adjustments such as brake adjustments. Nor does this warranty cover normal deterioration of the exterior finish due to use or exposure.



# The Pursuit of Value...



## White Shows the Way!

The only way to insure the performance of your product is to use original equipment parts and accessories. White Outdoor Products designs and engineers quality parts to exacting specifications. When you substitute, you take a chance on quality, reliability, safety and performance. Use White Outdoor Products original equipment parts—See your local White Outdoor dealer!

Model No.	-616E	-646F	-666H
Ignition Key	725-1660	725-1660	725-1660
Shave Plate	784-5581A	784-5579	784-5575
Skid Shoe	390-140-190	390-140-190	390-140-190
Auger Belts	754-0431	754-0430 (2 req'd.)	754-0430 (2 req'd.)
Drive Belt	754-0343	754-0346	754-0346
Friction Wheel Rubber	735-0243	735-0243	735-0243
Friction Wheel Ass'y. Comp.	684-0042	684-0042	684-0042
Spark Plug	J-8C	J-8C	J-8C
Engine Oil (SAE 5W30)	730226 (21 oz. req'd.)	730226 (26 oz. req'd.)	730226 (26 oz. req'd.)
Electric Start Kit	390-986-190	Standard	Standard
Tire Chains	390-139-190	390-991-190	390-665-190
Drift Cutter Kit	390-679-190	390-679-190	390-679-190
Snow Cab	390-674-190	390-674-190	390-674-190